










MB KEY MAKER

Instructions



1. Click  to select the model of the chip or the car
2. Click  to load the EEPROM data read out by using the 705 programmer
3. When the data is loaded, the lower screen will display , it means that the first, the second and the third key is in use.
4. Click  to select the key number. There are totally 8 keys available. Don't select the key number which is in use, otherwise the key will be erased.
5. Place the PCF7935 in the hole as shown in the figure, click  to begin to write the key. It takes about 1 minute for writing the key.



6. When the key is successfully written, the screen will display .
7. Insert the chip onto the key. The key is done!

Note: When writing keys for ML320, please correct all the red data to FF, and then perform the above operations

ML 320_AAM + PCF 7930/35

AAM	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00000000	FF	44	63	00	00	00	00	96	04	16	18	70	45	61	11	02
00000010	00	00	10	48	0C	01	00	00	16	48	FF	FF	FF	FF	05	37
00000020	10	20	1D	FF	34	97	FF	FF	FF	14	46	3C	1B	2F	1F	33
00000030	00	00	00	00	00	00	00	64	64	0A	64	64	14	1E	14	64
00000040	1E	32	02	00	44	11	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF
00000050	14	32	00	03	0E	0F	00	00	00	02	DD	0F	6A	A1	8A	AD
00000060	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	54	8E	90	FF	FF	FF
00000070	FF	FF	FF	FF	FF	37	28	05	C8	0A	0F	8E	7F	FF	02	59
00000080	D0	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF
00000090	FF	FF	78	F8	98	FF	FF	FF	FF	FF	FF	FF	FF	8A	02	E8
000000A0	A5	6C	07	55	37	FF	95	1B	7F	FF	FF	FF	FF	FF	FF	FF
000000B0	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	C0	B2	D4	FF	FF	FF
000000C0	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	BD	ED
000000D0	7C	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF
000000E0	FF	FF	46	3C	22	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF	FF
000000F0	FF	FF	FF	FF	FF	FF	2D	4F	3F	FF	FF	FF	FF	FF	FF	FF